

ITALIANO

PLAY-14 Funzioni aggiuntive sul funzionamento per freccette

PUNTEGGIO MEDIO PER FRECCETTA per la PARTITA ATTUALE.

Premendo il tasto **AVERAGE** viene visualizzato per 5 secondi il punteggio medio per freccetta relativo alla partita in corso o appena terminata. La media è visualizzata sulle prime due righe del segnapunti. Esempio: se il risultato è 36,363, viene visualizzato 36 sulla prima riga e 363 sulla seconda riga. Per ottenere la media esatta a fine partita quando si ha chiuso con 1 o 2 freccette anziché 3, premere rispettivamente i tasti gialli "1" o "2" e poi il tasto **AVERAGE**.

PUNTEGGIO MEDIO PER FRECCETTA per una SERIE DI PARTITE.

Premendo il tasto **F2** è possibile visualizzare il punteggio medio per freccetta realizzato su più partite.

Prima di iniziare una nuova serie di partite, è necessario cancellare la media precedente. Per fare ciò procedere nel seguente modo:

1. Azzerare il numero di partite vinte visualizzate sulla riga in basso, premendo i tasti "**C**" (destra e sinistra).
2. Effettuare una nuova partenza (premendo **START DART**, poi il punteggio di partenza ed **ENTER**).
3. Infine premere i tasti **F2** e poi **CANCEL**. La media precedente viene così azzerata.

ENGLISH

PLAY-14 Additional functions for Darts

Average per dart for the current game.

Pressing the **AVERAGE** button will show the average per dart of the game that is being played or has just been terminated. The average is shown on the first two lines. Example: 36.363 will show 36 on the top line and 363 on the second line. The figures are shown for five seconds.

To obtain the exact average at the end of a game when it has ended with 1 or 2 darts instead of 3, push the yellow "1" or "2" buttons respectively and then the **AVERAGE** button.

Average over sets of games.

It is possible to obtain the average per dart over a total of any number of legs (set) by pressing the **F2** button. Before commencing a new set or match it is necessary to cancel the previous averages. To do so proceed as follows:

1. Cancel the partial legs display (from the previous games) on bottom line by using the "**C**" buttons (left and right).
2. Press **START DART**, then **501** or whichever game has been chosen and **ENTER**.
3. Now press **F2** followed by **CANCEL**. The scorer is now ready for a new set.

Always remember to punch in "1" or "2" after entering last score if leg was closed on 1st. or 2nd. dart.