

Sub-floor box for fencing reel

(Art.904)

In few seconds the reel can be extracted and fixed above the sub-floor box cover or reinserted in the same, leaving free the floor for other activities.

- To avoid the shifting of the [reel](#), the sub-floor box cover has two suitable holes to insert the two detents made of two screws with a couple of nuts on each one, fixed on the bottom of the reel. Such Detents are provided with the sub-floor box and they must be screwed on the bottom of the reel replacing the two front closing screws.
- Inside the sub-floor box there is an adhesive cable tie holder on which fixing, by the suitable cable tie, [the cable that connect the device to the reel](#): set it up at about 20cm from the 3 pin plug. The surplus of cable, should be blocked on a internal sidewall of the sub-floor box using other adhesive cable tie holders, so that it could not bother the insertion or extraction of the reel.
- Sturdy cover made out in grey PVC and bottom in aluminium.
- Total dimensions: 45 x 45 x 12.5cm. Total weight 5.3kg.



Art.904

...Sub-floor Box for the Millennium reel

Size: 45x45x12,5cm. - Weight: 5.3kg.



Art.904A

...Sub-floor Minibox for apparatus cables

Size: 20x20x20cm. - Weight: 1.2kg.