

## LIST OF SOFTWARE VERSIONS AND CHANGES

# Full-Arm-05 Fencing Apparatus

Art. 831

## 1.1. T2016\_02\_FA5 version (22 Aug 2016).

---

The related Full-Arm-05 Manual is the document "00831-M01-04 - Full-Arm-05 User Manual".

1. Added the loading on the chronometer of 1 minute of bout time by double click of the [SET] key of the remote control. Useful for the additional time in case of parity.

## 1.2. T2016\_01\_FA5 version (19 May 2016).

---

The related Full-Arm-05 Manual is the document "00831-M01-03 - Full-Arm-05 User Manual".

This is the 1st T2016 version. Added the following features, compared to the T2005A version:

1. display on the chronometer of tenths of a second in the last 10 seconds and hundredths with the stopped clock (FIE request);
2. time for double hit for sabre:  $170 \pm 10$  ms (FIE request);
3. single operation mode for sabre;
4. for épée, added the operation mode without the automatic increase of the points;
5. weapon selection by [BLOCK] key of the remote control, operation mode selection by [REARM] key.

## LISTA DEI CAMBIAMENTI E DELLE VERSIONI SOFTWARE

# Full-Arm-05 Apparecchio per la scherma

Art. 831

## 1.1. Versione T2016\_02\_FA5 (22 Agosto 2016).

---

Il relativo manuale del Full-Arm-05 è il documento "00831-M01-04 - Full-Arm-05 User Manual".

1. Aggiunto il caricamento sul cronometro di 1 minuto di tempo di combattimento mediante doppio click del tasto [SET] del telecomando. Utile per il tempo supplementare in caso di parità.

## 1.2. Versione T2016\_01\_FA5 (19 Maggio 2016).

---

Il relativo manuale del Full-Arm-05 è il documento "00831-M01-03 - Full-Arm-05 User Manual".

Questa è la 1ª versione T2016. Aggiunte le seguenti funzionalità, rispetto alla versione T2005A:

1. visualizzazione sul cronometro dei decimi di secondo negli ultimi 10 secondi e dei centesimi con il cronometro fermo (richiesta FIE);
2. tempo per il colpo doppio nella sciabola:  $170 \pm 10$  ms (richiesta FIE);
3. singola modalità di funzionamento nella sciabola;
4. per la spada, aggiunto modo di funzionamento senza l'incremento automatico dei punti;
5. selezione dell'arma mediante il tasto [BLOCK] del telecomando, selezione del modo di funzionamento mediante il tasto [REARM].